

DK Betjeningsvejledning

GB User Manual

LED højttaler

80036733



VIGTIGT - FØR START!

Sørg for at tjekke at alle delene er intakte inden brug.

IMPORTANT – BEFORE START!

Make sure to check that all items are intact before usage.

Indeholder

1 x Transportabel LED højttaler.

1 x USB-kabel 0.8 m.

Specifikationer

Dimensioner	20,5 x 20,5 x 3,5 cm
Bluetooth version	5.0
Spænding	3.7-4.2V
Effekt	45MM, 3Wx2
Batteritype	Li-Ion batteri
Bluetooth højttalerens rækkevidde	10 m (32.8ft.)
Frekvensrespons	20HZ-20KHZ
Indgangseffekt	5.0V – 4"/3W
Opladningstid	4-8 timer

Funktioner

1. Den genopladelige LED højttaler kan skifte farve og er udstyret med en bluetooth højttaler.
2. LED højttaleren er genopladeligt og skal blot kobles til et USB kabel/stik.
3. Desuden er det muligt at koble to bluetooth enheder sammen, styret af blot en telefon.

Sikkerhedsforskrifter

- ⚠ Det indbyggede genopladelige batteri kan ikke udskiftes eller erstattes.
Batteriet må ikke tages ud eller udskiftes; hvis det skal bortskaffes, må det IKKE smides i skraldespanden. Det skal anskaffes efter de foranstaltninger der er for bortskaffes af batterier. Er du i tvivl om hvordan og hvor batterier bortskaffes, henvend dig da til de forskrifter der er anvist i din kommune, for afskaffelse af batterier.
- ⚠ Sørg for at USB-kablet er uden for børns rækkevidde.
- ⚠ Forsøg ALDRIG at åbne dækslet ved lysknappen.
- ⚠ Sørg altid for at frakoble enheden når det ikke er i brug.
- ⚠ Hvis produktet er gået i stykker eller blevet beskadiget på anden vis, må enheden IKKE anvendes.

Sørg for at holde LED højttaleren væk fra flammer, ild og kemikalier.

⚠ Enheden må IKKE oplades udenfor, det skal oplades indendørs.

Betjening

Enheden tændes ved at holde S-power- knappen inde.

For at tænde LED lyset, trykkes der på **LED MODE** knappen.

Tryk dobbelt på LED knappen for at få tændt for TWS eller Bluetooth synkroniseringen.

Tænd derefter for højttaleren og vælg **BLUETOOTH MODE**.

Find derefter dine Bluetooth indstillinger på din smart phone eller tablet. Vælg **UUFFOO** og indtast koden **0000** (nogle enheder behøver ikke denne kode), for at koble enhederne sammen.

LED højttaleren vil efterfølgende indikere at sammenkobling er lykkedes.

Batteriopladning

- Før du tager produktet i brug, skal LED højttaleren oplades i 6-8 timer.
- Oplad LED højttaleren ved at anvende USB-kablet som medfulgte; USB-kablet kan anvendes i en computer, telefon eller oplader (5V).
- Koble USB-kabel til USB-porten i computeren.
- Indsæt USB-kablet i stikket på LED højttaleren.
- LED højttaleren vil indikere hvornår den er fuldt opladet. Dette vises ved at indikatorlampen lyser grønt.
- Når LED højttaleren er fuldt opladet, sørg da for at dække opladningstikket til inden den tages i brug.
- Nu er LED højttaleren klar til at tages i brug.

Opret forbindelse til Bluetooth

1. Sørg for at enhedens LED højttaler er tændt (**ON**).
2. Når enheden er tændt, vil den give en hørbar lyd/bip, som indikerer at enheden er klar til at blive forbundet. Inden forbindelsen er oprettet, vil enheden blinke blå.
3. Væg **UUFFOO** under dine Bluetooth indstillinger, for at forbinde din telefon eller tablet med LED højttaleren. En anden hørbar lyd/bippen vil indikere at enhederne nu er forbundet til hinanden.

Ønsker man at slukke eller afbryde forbindelsen, kan man:

1. Slå Bluetooth fra på din telefon eller tablet. Gøres dette vil LED højttaleren indikere at de to enheder er frakoblet hinanden, ved at udgive en hørbar lyd/bippen.

2. Sluk for LED højtaleren og forbindelsen til telefonen eller tabletten vil automatisk blive afbrudt.

OBS! Vær opmærksom på, at hvis enheden ikke opretter forbindelse inden for 20 minutter, vil den automatisk gå på strømbesparelsestilstand.

Parring af to LED højtalere

Sørg for at parre de to højtalere først, inden du kobler dem sammen med din telefon eller tablet.

Første gang 2 højtalere forbindes

1. Tryk på **ON/OFF**- knapperne på de to enheder.
2. Efter begge højtalere er tændt, skal du dobbeltklikke på **ON/OFF**-knapperne, der vil efterfølgende komme en biplyd som indikerer at de nu er klar til at blive forbundet.
3. Nu er LED højtalerne klar til at blive forbundet til enten din telefon eller tablet.

Opbevaring og vedligeholdelse

Sørg altid for at slukke på OFF-knappen, når enheden ikke er i brug.

Sørg for at LED højtaleren ikke opbevares for koldt (under 0 grader) ej heller for varmt, da det kan have en indflydelse på produktets funktionsevne og levetid.

Skal LED højtaleren opbevares i længere tid, skal temperaturen være imellem 0-25 grader.

OBS! Hvis LED højtaleren ligger opbevaret mere end 3 måneder uden at blive brugt, skal den oplades inden den tages i brug igen.

Content

1 x Portable LED speaker.

1 x USB charging cable 0,8 m.

Specifications

The LED speaker is made of ABS plastic – a versatile plastic material.

The operating of the LED speaker is 6 hours if it only plays music.

If both music and the light is on, the speaker will be able to play for 3 hours.

The LED speaker is wireless and has the perfect size to fit your sunshade.

It does not take up much space and it gives a very nice, warm, and cozy light.

In addition, the color of the LED speaker/lamp can be changes for more festive occasions.

The LED speaker is intended to sit under the sunshade, but it can also be used both indoors and outdoors.

Dimensions	20,5 x 20,5 x 3,5 cm
Bluetooth version	5.0
Output voltage	3.7-4.2V
Output power	45MM, 3Wx2
Battery	Li-Ion battery
Bluetooth operating distance	10 m (32.8ft.)
Frequency response	20HZ-20KHZ
Input	5.0V – 4"/3W
Chargingtime	4-8 hours

Functions

1. The rechargeable LED speaker can change color and is equipped with a Bluetooth speaker.
2. The LED speaker is rechargeable and simply needs to be connected to a USB cable/plug.
3. In addition, it is possible to connect two Bluetooth devices/units, controlled by only one phone or tablet.

Safety regulations

⚠ The built-in rechargeable battery cannot be replaced.

The battery must not be removed or replaced; if it is to be disposed of it must NOT be thrown in the trash. It must be acquired according to the measures for disposal of batteries. If you are in doubt, how and where to dispose the battery, refer to the regulations set out by the government for the disposal of batteries.

⚠ Make sure that the USB cable is out of reach for children.

⚠ NEVER try to open the light switch cover.

⚠ Always make sure to unplug the device when not in use.

⚠ Do NOT jump, kick or throe the LED speaker.

⚠ If the product is broken or otherwise damaged, the device must not be used. Please contact dealer if this is the case.

⚠ Make sure to keep the LED speaker away from flames, fire and chemicals.

⚠ The device must NOT be charged outside, it must be charged indoors.

Operation

The device is turned on by pressing down the S-power button.

To turn on the LED light, press the **LED MODE** button.

Double press the LED button to turn on the TWS or Bluetooth synchronization.

Then turn on the speaker and select **BLUETOOTH MODE**.

Find your Bluetooth settings on your smart phone or tablet. Select **UUFFOO** and enter the code **0000** (some devices do not need this code) to pair the devices.

Then, the LED speaker will subsequently indicate that the pairing has been successful.

Recharging of battery

- Before using the product, the LED speaker must be charged for 6-8 hours.
- Charge the LED speaker by using the supplied USB cable. The USB cable can be used in a computer, telephone, or charger (5V).
- Connect the USB cable to the USB port in the computer.
- Insert the USB cable into the socket on the LED speaker.

- The LED speaker will indicate when it is fully charged. This is indicated by the indicator lamp, which will display a green light when finished.
- When the LED speaker is fully charged, make sure to cover the charging plug before using the unit.
- Now, the LED speaker is ready to be use.

Connect to Bluetooth

1. Make sure the device's LED speaker is switched **ON**.
2. When the device is powered ON, it will make an audible sound/beep indicating that the device is ready to connect. Before the connection is established, the device will flash blue.
3. Add **UUFFOO** under your Bluetooth settings to connect your phone or tablet to the LED speaker. Another audible sound/beep will indicate that the devices are now connected to each other.

If you want to switch off or disconnect the connection, you can:

1. Turn off Bluetooth on your phone or tablet. If this is done, the LED speaker will indicate that the two devices are disconnected from each other by emitting an audible sound/beep.
2. Switch off the LED speaker and the connection to the phone or tablet will automatically be disconnected.

ATTENTION! Please nota that if the device does not connect within 20 minutes, it will automatically enter power saving mode.

Pairing of the LED speakers

Make sure to pair the two speakers first before pairing them with your phone or tablet.

The first time 2 speaker are connected

1. Press the ON/OFF buttons on the two devices.
2. After both speakers are switched on, double-click the **ON/OFF** buttons, a beep will then be heard to indicate that they are now ready to be connected.
3. Now the LED speakers are ready to be connected to either your phone or tablet.

Storage and maintenance

Always make sure to turn off the OFF button when the unit is not in use.

Make sure that the LED speaker is not stored too cold (below 0 degrees) nor too hot, as this can have an impact on the product's functionality and lifespan.

If the LED speaker is to be stored for a long time, the temperature must be between 0-25 degrees.

ATTENTION! If the LED speaker is stored for more than 3 months without being used, it must be charged before being used again.

MORELAND A/S
KNULLEN 22
5260 ODENSE S