



Open the base, adjust the height of the pole as photo shows, take out the badminton net.

3 adjustable height :
107 cm for tennis net;
155 cm for badminton net;
120 cm for badminton net



Fix the net on the pole, fix and adjust the length of tension strap, fix ground pegs into the ground as photo shows.