



# Wall Mount Basketball Set Instruction

ZY-006



# Pack contents



**A** 4 x 75mm Expansion bolts




**B** 2 x Bolts




**C** 2 x Bolts




**D** 2 x Wall plugs




**E** 1 x Backboard



**F** 1 x Net



**G** 1 x Rim



**H** 1 x Rim

# Step 1: Placing backboard and rim onto the wall

- 1) Locate the desired position for the backboard on the wall. Locate an area away from windows and obstructions. The wall surface should be flat and ideally be brick or of a smooth sound rendering. Undulating, uneven or porous surfaces are not suitable for this installation. If in doubt consult a qualified builder for advice. Normal playing height is 3.04 metres (10ft) from the top edge of the rim to the playing surface. For younger players a lower playing height is recommended.
- 2) Place the backboard (H) against the wall in the desired position. Check for squareness with a spirit level. Mark the six hole positions through the backboard with a marker pen.
- 3) Drill the six holes with an 10mm drill bit to a depth of 65mm. To accomodate the expanding bolts (A) and plugs (D).
- 4) Open out the arms on the wall bracket (H) so that the holes align with the holes on the backboard (E).
- 4) Insert the expanding bolts (A) and wall plugs (D) into the wall. The expanding bolts (A) bolts should protrude 10mm.
- 5) Slide the bracket (H), backboard (E) and rim (G) onto the four expanding bolts (A) and secure into position using the nuts and washers (A).
- 6) Insert bolts (B) into the top holes with washers (C). Tighten all bolts securely.
- 7) Attach the net (F) to the net hooks on the rim (G).

